






# MULTIMO













## A-213 STUDIO 5













Assembly Instructions

Track Title	(inch)				(mm)			
	Piece	Thickness	Length	Width	Piece	Thick	Height	Most
A		1,18	89,76	23,62	2	30	2280	600
B		0,71	83,86	23,62	1	18	2130	600
C		1,18	83,86	22,83	1	30	2130	580
D		0,71	87,40	19,29	1	18	2220	490
E		0,71	41,57	18,50	3	18	1056	470
F		0,71	41,57	7,48	2	18	1056	190
G		0,71	7,87	18,31	2	18	200	465
H		0,71	13,78	18,50	2	18	350	470
I		0,71	41,57	5,12	2	18	1056	130
K		0,71	9,37	4,92	1	18	238	125
L		0,71	11,42	20,63	2	18	290	524
M		0,71	31,50	20,47	1	18	800	520
N		0,71	31,50	13,78	1	18	800	350
O		0,71	31,50	7,68	1	18	800	195
P		0,71	31,50	20,47	1	18	800	520
R		0,71	29,53	10,59	2	18	750	269
S		0,71	29,53	14,76	2	18	750	375
T		0,71	85,75	42,13	2	18	2178	1070
U		0,71	32,28	7,68	2	18	820	195
Y		0,71	7,87	7,87	4	18	200	200
Z		6,61	36,06	16,54	2	168	916	420
X		0,31	88,94	21,06	4	8	2259	535

## Accessories List

<b>MXN 02</b>  <b>70 / piece</b>	<b>MNG - 01</b>  <b>70 / piece</b>	<b>KVL 01</b>  <b>84 / piece</b>	<b>VD - 03 ( 3,5x18 ) mm</b>  <b>22 / piece</b>
<b>VDA - 01 ( 6,5x50 ) mm</b>  <b>6 / piece</b>	<b>VD - 02 (3,5x25) mm</b>  <b>30 / piece</b>	<b>IM - 04 (6x15) mm</b>  <b>2 / piece</b>	<b>IM - 01 (6x30) mm</b>  <b>2 / piece</b>
<b>OT 01</b>  <b>4 / piece</b>	<b>TS - 03</b>  <b>4 / piece</b>	<b>AF - 02</b>  <b>2 / piece</b>	<b>BO - 01</b>  <b>1 / piece</b>


<b>YY 01</b>  <b>2 / piece</b> <b>MKZ - 02</b>  <b>2 / piece</b> <b>450N</b> <b>AL - 01</b>  <b>4</b>	<b>KOR 01</b>  <b>1 / piece</b> <b>STP - 01</b>  <b>4 / piece</b>	<b>KLF 01 (fabric cover)</b>  <b>1 / piece</b> <b>TTC 01</b>  <b>4 / piece</b>	<b>H 01</b>  <b>3 / piece</b> <b>AL - 02</b>  <b>5</b>
---	--	---	---




## STEP 1




MNX - 02




KVL 01




## STEP 2





**STEP 3**





**STEP 4**




**STEP 5**




**STEP 6**



## STEP 7




## STEP 8







# STEP 9



# STEP 10




# STEP 11






x10


210°



# STEP 12



VD - 03




BO - 01





AF - 02


## STEP 13






## STEP 14



## STEP 15



**CAUTION**  
**DO NOT UNLOCK BEFORE INSTALL**



# STEP 16



Ø 10 mm / 0,254 inch


DD - 02

PL - 01

VD - 01

VTB - 01



DSE - 01



# STEP 16



Ø 10 mm / 0,254 inch




FIRST LOCATE THE STUDS BY USING "STUD FINDER" IN THE WALL AND DRILL IT ACCORDING TO THE HEIGHT MEASUREMENTS GIVEN ON THE SIDE.

UPPER HOLES SHOULD BE DRILLED FOR ATTACHING BED AT NEXT STEP.

SUPPLY DRYWALL FASTENERS APPROPRIATE TO YOUR WALL TYPE. WE RECOMMEND USING STEEL TOGGLE BOLT ANCHOR THAT SHOWN BELOW






## STEP 17



### CAUTION

MAKE SURE THE FRONT PANEL IS ALL THE WAY INSIDE THE TONNELS


45-50°




PULL DOWN GENTLY TO RELISE THE HOLDING TRIGGER LOCK





## STEP 18



## STEP 19




## STEP 20







**STEP 21**



**STEP 22**




## STEP 23



**KVL 01**


## STEP 24




**MNG - 01**

**x4**

**210°**



## STEP 25




KVL 01




MNG - 01

x4

210°




## STEP 26




MNG - 01

x4


210°



**STEP 27**




**STEP 28**




x12



210°



## STEP 29




## STEP 30



OT 01






YY 01




## STEP 31

**CAUTION !**  
BE SURE THE HEADBOARD  
IS IN CLOSED POSITION  
WHEN BED BOX IS CLOSED


KLF 01 (fabric cover)



### STEP A



### STEP B



1. Unless an item is free standing, when mounting on a regular drywall, furniture must be fastened to wood or metal studs. Solid walls made of brick, concrete or similar materials are also acceptable. Do not mount furniture on to paper-mache or sheetrock like material without properly affixing it to stud.
2. For safety and longevity of the product you must periodically inspect the mounting and mechanical connections for integrity and tightness. Confirm that hardware remains properly affixed and connections are snug.
3. Unless noted otherwise on the product page, Wall Bed mattress thickness may not exceed 8 inch. Make sure to remove pillows and excess blankets before closing. This keeps mechanism free of obstructions and unnecessary stress.
4. Do not lean or rest heavy objects on sides or top of furniture. This may cause balance issues and compromise the integrity of your mounting connections.
5. Please use beds, desks and shelving as intended. Improper use may cause personal injury and damage to property.
6. With seasonal humidity change you must inspect interior and exterior of furniture.
7. Single, Twin, Twin XL beds accommodate the weight of one person, up to 250 lb. Exceeding recommended weight restrictions may lead to personal injury and property damage.
8. Before any un-mounting or disassembly please contact Multimo for technical support and instructions. Failure to properly detach wall bed may result in personal injury and property damage.
9. Some wall beds have legs that fully extend when open - be aware of where the leg is and will be.



## WARNING

### IMPORTANT! HAZARD WARNING!

All Wall Beds contain sophisticated and powerful lifting mechanism.  
Failure to follow assembly and installation instructions may result in **severe personal injury and damage of the product.**

### SECURE RIGIDLY TO A WALL!

Improper attaching wall bed to a wall will create a tip-over hazard and may result in severe personal injury or even death.  
**ONLY qualified installers should install or remove a wall bed.**



10. For Bunk Beds:

- a. Always use provided ladder when accessing top bunk.
- b. Be slow, careful and aware of surroundings when opening top bunk.
- c. Do not horseplay. Beds are to be slept on only.



## WARNING

**To help prevent serious or fatal injuries due to entrapment or falls**

- Never allow a child under 6 on upper bunk.
- Use only Twin/Twin XL size mattress on upper bunk.
- Ensure mattress thickness doesn't exceed 6", and that mattress surface at least 5" below upper edge of guard rails



## WARRANTY

### RETAIL RESIDENTIAL TERM

Lifetime guarantee on hardware.

**5 year** structural guarantee on cabinetry.

---

### COMMERCIAL TERM

Lifetime guarantee on hardware.

**2 year** structural guarantee on cabinetry.



[www.multimobeds.com](http://www.multimobeds.com)